

pulsar
NS400



THE WORLD'S
FAVOURITE
INDIAN

pulsar
NS400

BS VI

Bajaj Auto Limited

Akurdi, Pune - 411 035, India.

Tel : +91 20 27472851

Fax : +91 20 27407385

Customer care : +91 7219821111

Website : www.bajajauto.com

CIN L65993PN2007PLC130076

Spare Parts Catalogue



Notice

All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

DOC. NO.: 71120225

REV. 00 JUN 24

Copy rights : All rights reserved. No part of this publicatin may be reproduced, stored in a retrival system, Or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Bajaj Auto LTD.

Foreword



We have pleasure in presenting the Spare Parts Catalogue for 'Pulsar NS400Z'. This catalogue has been specially designed to assist you in selecting the correct parts for procurement to maintain 100% availability.

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve Performance and Efficiency of the vehicles, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications / alterations which are carried out after the issue of this catalogue, will be conveyed to you through our Service Circulars. You are requested to make necessary corrections in the Parts Catalogue as per the circulars so as to keep your catalogue up-to-date. This will ensure the appropriate and speedy delivery of the Spare Parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Bajaj Auto Limited
Service Department
Akurdi, Pune 411 035 India

Instructions



1. How to Read the Catalogue : Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

2. How to Order Spare Parts : The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

3. Part Number System : We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

4. Abbreviations : The following abbreviations are used in this catalogue.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
Rr.	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required

pulsar
NS400

pulsar
NS400

pulsar
NS400

pulsar
NS400

Index



Plate No.	Description	Page No.
1	Cover Cylinder Head	2
2	Cylinder Head	4
3	Rocker arm & Camshaft	6 - 10
4	Chain Guide & Tensioner Assembly	12
5	Cylinder & Piston	14
6	Crankshaft Assembly	16
7	Transmission	18
8	Change Drum / Shift Fork	20
9	Gear Change Mechanism	22
10	Engine Assembly / Crankcase RH	24
11	Crankcase LH	26 - 28
12	Balancer Idler Gear & Water Pump	30
13	Oil Pump & Evacuation Pump	32
14	Cooling System	34 - 36
15	Cover Clutch	38
16	Cover Magneto	40
17	Clutch Assembly & Clutch Cable	42
18	Throttle Body & Sensors	44
19	Air Cleaner Assembly	46
20	Silencer Assembly	48
21	Starter Assembly	50
22	Magneto, Regulator & ECU	52
23	H.T. Coils	54
24	Seat Assembly & Seat Lock	56
25	Engine Mountings	58
26	Frame & Frame Fittings	60
27	Swing Arm & Rear Shock Absorber	62 - 64
28	Belly Pan & Radiator Shroud	66
29	Rider & Pillion Foot Rest	68 - 70
30	Front Fender	72
31	Side Stand Assembly	74
32	Tubeless Tyre & Wheel	76
33	Front Wheel Hub	78

Index



Plate No.	Description	Page No.
34	Master Cylinder - Front	80
35	Caliper Assembly - Front	82
36	Anti Lock Brake System	84
37	Rear Disc Brake Master Cylinder & Caliper	86
38	Rear Wheel Hub	88
39	Rear Brake Pedal	90
40	Handle Bar Assembly	92 - 94
41	Front Fork	96
42	Petrol Tank, Cap Tank & Gauge Fuel	98
43	EVAP Mechanism	100
44	Fitting - Petrol Tank Cover	102
45	Fitting - Side Covers, Seat Cowl	104
46	Instrument Cluster & Socket Charger	105
47	LED Head Lamp & Fairing	108 - 110
48	Indicator Light Assembly	112
49	Tail Lamp Assembly & Number Plate Mounting	114
50	Electrical Equipments	116 - 118
51	Tool Kit	120
52	Accessories - Mirror, Leg Guards, Grab Handles & Saree Guard	122
53	Painted Parts and Decals	124 - 130
54	Consumable Parts	132 - 134
	Kit List	134- 140
	Amended Sheet (Parts Added)	141
	Amended Sheet (Parts Deleted)	142
	Part Index	143

Pictorial Index

pulsar
NS400

PLATE NO. : 1
COVER CYLINDER HEAD

PAGE NO.
1



PLATE NO. : 2
CYLINDER HEAD

PAGE NO.
3




PLATE NO. : 3
ROCKER ARM & CAMSHAFT

PAGE NO.
7-11





PLATE NO. : 4
CHAIN GUIDE & TENSIONER ASSEMBLY

PAGE NO.
11



Pictorial Index

pulsar
NS400

PLATE NO. : 5
CYLINDER & PISTON

PAGE NO.
13




PLATE NO. : 6
CRANKSHAFT ASSEMBLY

PAGE NO.
15




PLATE NO. : 7
TRANSMISSION

PAGE NO.
17





PLATE NO. : 8
CHANGE DRUM / SHIFT FORK

PAGE NO.
19



Pictorial Index

pulsar
NS400

PLATE NO. : 9
GEAR CHANGE MECHANISM

PAGE NO.
21




PLATE NO. : 10
ENGINE ASSEMBLY / CRANKCASE RH

PAGE NO.
23




PLATE NO. : 11
CRANKCASE LH

PAGE NO.
25 - 27





PLATE NO. : 12
BALANCER IDLER GEAR &
WATER PUMP

PAGE NO.
29



Pictorial Index

pulsar
NS400

PLATE NO. : 13
OIL PUMP & EVACUATION PUMP

PAGE NO.
31




PLATE NO. : 14
COOLING SYSTEM

PAGE NO.
33 - 35




PLATE NO. : 15
COVER CLUTCH

PAGE NO.
37





PLATE NO. : 16
COVER MAGNETO

PAGE NO.
39



pulsar
NS400

PLATE NO. : 18 THROTTLE BODY & SENSORS	PAGE NO. 43

[illegible]

pulsar
NS400

PLATE NO. : 22 MAGNETO, REGULATOR & ECU	PAGE NO. 51
--	----------------

This diagram illustrates the exploded view of a Magneto, Regulator & ECU assembly. The components are numbered as follows:

- 1:** Green cylindrical component, likely the stator or rotor housing.
- 2:** Green circular component, possibly a rotor or stator core.
- 3:** Green circular component with a central hole, likely a rotor or stator core.
- 4:** Black rectangular component, possibly a regulator or ECU housing.
- 5:** Blue component, possibly a regulator or ECU housing.
- 6:** Blue component, possibly a regulator or ECU housing.
- 7:** Grey rectangular component, possibly a regulator or ECU housing.
- 8:** Green component, possibly a regulator or ECU housing.
- 9:** Yellow component, possibly a regulator or ECU housing.
- 10:** Red component, possibly a regulator or ECU housing.
- 11:** White component, possibly a regulator or ECU housing.
- 12:** Red component, possibly a regulator or ECU housing.
- 13:** Green component, possibly a regulator or ECU housing.
- 14:** Blue component, possibly a regulator or ECU housing.
- 15:** Blue component, possibly a regulator or ECU housing.
- 16:** White component, possibly a regulator or ECU housing.
- 17:** White component, possibly a regulator or ECU housing.
- 18:** Blue component, possibly a regulator or ECU housing.
- 19:** Blue component, possibly a regulator or ECU housing.
- 20:** Yellow component, possibly a regulator or ECU housing.
- 21:** Yellow component, possibly a regulator or ECU housing.
- 22:** Yellow component, possibly a regulator or ECU housing.
- 23:** Blue component, possibly a regulator or ECU housing.
- 24:** Blue component, possibly a regulator or ECU housing.

PLATE NO. : 24 SEAT ASSEMBLY & SEAT LOCK	PAGE NO. 55
---	----------------

The diagram illustrates the assembly of a seat and its locking mechanism. The components are numbered as follows:

- 1**: Blue seat backrest.
- 2**: Three red bushings.
- 3**: Green bushing.
- 4**: Metal pin.
- 5**: Metal pin.
- 6**: Metal pin.
- 7**: Metal pin.
- 8**: Metal pin.
- 9**: Black base plate.
- 10**: Green braided hose.
- 11**: Metal pin.
- 12**: Metal pin.
- 13**: Metal pin.

Pictorial Index

pulsar
NS400

PLATE NO. : 25
ENGINE MOUNTINGS

PAGE NO.
57




PLATE NO. : 26
FRAME AND FRAME FITTINGS

PAGE NO.
59




PLATE NO. : 27
SWING ARM & RSA

PAGE NO.
61 - 63





PLATE NO. : 28
BELLY PAN & RADIATOR SHROUD

PAGE NO.
65



Pictorial Index

pulsar
NS400

PLATE NO. : 29
RIDER & PILLION FOOT REST

PAGE NO.
67 - 69




PLATE NO. : 30
FRONT FENDER

PAGE NO.
71



PLATE NO. : 31
SIDE STAND ASSEMBLY

PAGE NO.
73









PLATE NO. : 32
TUBELESS TYRE & WHEELS

PAGE NO.
75







Pictorial Index

pulsar
NS400



Pictorial Index

pulsar
NS400



Pictorial Index

pulsar
NS400

PLATE NO. : 41
FRONT FORK

PAGE NO.
95




PLATE NO. : 42
PETROL TANK, CAP TANK & GAUGE
FUEL

PAGE NO.
97




PLATE NO. : 43
EVAP SYSTEM

PAGE NO.
99





PLATE NO. : 44
FITTING - PETROL TANK COVER

PAGE NO.
101



Pictorial Index

pulsar
NS400

PLATE NO. : 45
FITTING - SIDE COVERS, SEAT COWL

PAGE NO.
103




PLATE NO. : 46
INSTRUMENT CLUSTER & SOCKET
CHARGER

PAGE NO.
105




PLATE NO. : 47
LED HEAD LAMP & FAIRING

PAGE NO.
107





PLATE NO. : 48
INDICATOR LIGHT ASSEMBLY

PAGE NO.
111



Pictorial Index



PLATE NO. : 49 TAIL LAMP ASSEMBLY & NUMBER PLATE MOUNTING	PAGE NO. 113
---	-----------------




PLATE NO. : 51 TOOL KIT	PAGE NO. 119
----------------------------	-----------------




PLATE NO. : 40 ELECTRICAL EQUIPMENTS	PAGE NO. 115 - 117
---	-----------------------






PLATE NO. : 52 ACCESSORIES - MIRROR GRAB HANDLES & SAREE GUARD	PAGE NO. 121
--	-----------------



Pictorial Index



PLATE NO. : 53 PAINTED PARTS & DECALS	PAGE NO. 123 - 129
--	-----------------------



--	--






PLATE NO. : 54 CONSUMABLE PARTS	PAGE NO. 131 - 133
------------------------------------	-----------------------




--	--






Cover Cylinder Head

No.	Part No.	Description	Qty.	Remarks
1	JG511022	Bolt special	4	
2	JG511021	Washer	4	
3	52DT0657	Cylinder head cover assembly	1	
4	JY511128	Gasket Rubber - Head Cover	1	
5	JY511139	Gasket head cylinder	1	




Cylinder Head

No.	Part No.	Description	Qty.	Remarks
1	KAED0635	Bolt flanged small	4	
2	KAEQ0640	Bolt flange small - M6	2	
3	KAEG0645	Bolt flanged small	2	
4	JY511058	Guide chain top	1	
5	52JF2943	Head cylinder - holder camshaft	1	
6	JY511068	Sleeve spark plug	1	
7	LJA00001	'O' Ring	2	
8	JY511074	Gasket sleeve spark plug	1	
9	LAC00032	Bolt socket head M10	4	
10	DK101225	Oil Pressure Switch	1	
11	DK101340	'O' Ring	1	
12	JG351400	Coolant Water Temp Sensor	1	
13	JG511020	'O' Ring	1	
14	JL581406	Pipe Intake	1	
15	LBC00003	Screw	3	
16	JY581404	O - ring intake pipe	1	
17	JY581405	Clamp intake pipe	2	
18	JG511046	Stud	2	
19	JL402219	Pigtail oil pressure switch	1	




Rocker arm & Camshaft

No.	Part No.	Description	Qty.	Remarks
1	JY511212	Rocker arm decomp	1	
2	JU511204	Rocker arm	3	
3	JY511226	Rocker arm shaft	2	
4	JG511016	Plug	2	
5	39102121	Ring - O	2	
6	JF511255	Camshaft assembly exhaust	1	
7	CB101022	Cotter Valve	8	
8	36JF0198	Kit valve repair K10UG	1	
9	JF511253	Camshaft assembly intake	1	
10	CB101009	Seal Valve Stem	4	
11	JY511221	Valve intake	2	
12	DT511270	Valve exhaust	2	
13	36JY0029	Kit Shim 2 mm	1	
14	36JF0104	Kit Shim 3.18 mm	1	
15	36JF0105	Kit Shim 3.20 mm	1	
16	36JY0030	Kit Shim 2.04 mm	1	
17	36JY0031	Kit Shim 2.08 mm	1	
18	36JY0032	Kit Shim 2.12 mm	1	
19	36JY0033	Kit Shim 2.16 mm	1	
20	36JY0034	Kit Shim 2.20 mm	1	
21	36JY0035	Kit Shim 2.24 mm	1	
22	36JY0036	Kit Shim 2.28 mm	1	
23	36JY0056	Kit Shim 2.30 mm	1	
24	36JY0037	Kit Shim 2.32 mm	1	
25	36JY0057	Kit Shim 2.34 mm	1	




Rocker arm & Camshaft

No.	Part No.	Description	Qty.	Remarks
26	36JY0038	Kit Shim 2.36 mm	1	
27	36JY0058	Kit Shim 2.38 mm	1	
28	36JY0039	Kit Shim 2.40 mm	1	
29	36JY0059	Kit Shim 2.42 mm	1	
30	36JY0040	Kit Shim 2.44 mm	1	
31	36JY0060	Kit Shim 2.46 mm	1	
32	36JY0041	Kit Shim 2.48 mm	1	
33	36JY0061	Kit Shim 2.50 mm	1	
34	36JY0042	Kit Shim 2.52 mm	1	
35	36JY0062	Kit Shim 2.54 mm	1	
36	36JY0043	Kit Shim 2.56 mm	1	
37	36JY0063	Kit Shim 2.58 mm	1	
38	36JY0044	Kit Shim 2.60 mm	1	
39	36JY0064	Kit Shim 2.62 mm	1	
40	36JY0045	Kit Shim 2.64 mm	1	
41	36JY0046	Kit Shim 2.68 mm	1	
42	36JF0089	Kit Shim 2.70 mm	1	
43	36JY0047	Kit Shim 2.72 mm	1	
44	36JF0090	Kit Shim 2.74 mm	1	
45	36JY0048	Kit Shim 2.76 mm	1	
46	36JF0091	Kit Shim 2.78 mm	1	
47	36JY0049	Kit Shim 2.80 mm	1	
48	36JF0092	Kit Shim 2.82 mm	1	
49	36JY0050	Kit Shim 2.84 mm	1	
50	36JF0093	Kit Shim 2.86 mm	1	



Rocker arm & Camshaft

No.	Part No.	Description	Qty.	Remarks
51	36JY0051	Kit Shim 2.88 mm	1	
52	36JF0094	Kit Shim 2.90 mm	1	
53	36JY0052	Kit Shim 2.92 mm	1	
54	36JF0095	Kit Shim 2.94 mm	1	
55	36JY0053	Kit Shim 2.96 mm	1	
56	36JF0096	Kit Shim 2.98 mm	1	
57	36JY0054	Kit Shim 3.00 mm	1	
58	36JF0097	Kit Shim 3.02 mm	1	
59	36JY0055	Kit Shim 3.04 mm	1	
60	36JF0098	Kit Shim 3.06 mm	1	
61	36JF0099	Kit Shim 3.08 mm	1	
62	36JF0100	Kit Shim 3.10 mm	1	
63	36JF0101	Kit Shim 3.12 mm	1	
64	36JF0102	Kit Shim 3.14 mm	1	
65	36JF0103	Kit Shim 3.16 mm	1	




 Front Wheel Direction

Plate No.: 4


Chain Guide & Tensioner Assembly

No.	Part No.	Description	Qty.	Remarks
1	36JF0197	Kit cam chain guide	1	
2	JY511220	Chain timing	1	
3	JY541009	Bolt Special Pivot Guide Chain	1	
4	CS101128	Gasket	1	
5	JF511249	Tensioner Assembly	1	
6	KAEW0620	Hex Bolt With Flange	2	
7	39266921	O - Ring	1	
8	JG511270	Bolt flanged - M6	1	



Cylinder & Piston

No.	Part No.	Description	Qty.	Remarks
1	36JF0196	Kit block piston	1	
2	39218106	Hollow Dowel Pin	2	
3	JF521017	Gasket Cylinder Block	1	
4	36JF0060	Kit Piston Ring	1	
5	JF521300	Circlip	2	




FWD Front Wheel Direction

Plate No.: 6


Crankshaft Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF531021	Balancer Drive Gear	1	
2	LDH00002	Belleville Washer	1	
3	LDB00033	Plain Washer	1	
4	JG531040	Nut Balancer Drive Lock	1	
5	39260607	Parallel Pin	1	
6	JY551212	Gear Primary Drive	1	
7	LFB00001	Sunk Key	1	
8	JY531026	Sprocket crankshaft (18T)	1	
9	JY531008	Plain Washer	1	
10	DG101275	Washer	1	
11	LCG00002	Nut Sprocket Drive Lock	1	
12	JP531025	Crankshaft Assembly Comp.	1	
13	36JF0054	Kit Primary Drive & Driven	1	
14	KFAB4050	Key Woodruff	1	
15	LAD00263	Bolt Flanged M8.5X0.75	2	




Transmission

No.	Part No.	Description	Qty.	Remarks
1	JY551022	Shaft Input	1	
2	JY551230	Gear 5th Drive	1	
3	JY551010	Bush 5th Drive	1	
4	JY551214	Circlip	2	
5	JY551229	Gear 3rd - 4th Drive	1	
6	JY551021	Bush 6th Drive	1	
7	JY551231	Gear 6th Drive	1	
8	JY551228	Gear 2nd Drive	1	
9	JY551215	Thrust Washer	1	
10	JY551006	Bush 2nd Driven	1	
11	JY551233	Gear 2nd Driven	1	
12	JY551008	Shaft Output T/M With Plug	1	
13	JY551237	Gear 6th Driven	1	
14	JY551235	Gear 4th Driven	1	
15	JY551005	Thrust Washer 3rd Driven	1	
16	JY551234	Gear 3rd Driven	1	
17	JY551027	Bush 3rd Driven	1	
18	JY551218	Circlip	1	
19	JY551236	Gear 5th Driven	1	
20	JY551205	Bush 1st Driven	1	
21	JY551232	Gear 1st Driven	1	
22	JY551217	Thrust Washer	1	
23	JY551018	'O' RING	1	
24	36JY0102	Kit Out Put Shaft Oil Seal	1	
24A	JY551033	Collar Sprocket	1	
25	LAE00017	Bolt Flanged	2	
26	JY551030	Plate Drive Sprocket	1	




Change Drum / Shift Fork

No.	Part No.	Description	Qty.	Remarks
1	JG561222	Guide Gear Shift	1	
2	DH101389	Socket Head Bolt	1	
3	JG561010	Spacer	1	
4	39260607	Parallel Pin	1	
5	JY561013	Drum Gear Shift	1	
6	JP351005	Sensor Assembly Pick Up	1	
7	JY561004	Shaft Input Gear Shift Fork	1	
8	JF561001	Shaft Output Fork Shift	1	
9	JY541039	Compression Spring	2	
10	JY561008	Fork Shift Output	2	
11	JY561002	Fork Gear Shift Input	1	
12	JN181033	Bolt	2	




Gear Change Mechanism

No.	Part No.	Description	Qty.	Remarks
1	JY561205	Lever Complete Change Shaft	1	
2	JG561215	Spring Compression	1	
3	JG561217	Bush Torsion Spring	1	
4	JG561218	Torsion Spring	1	
5	JG561216	Plain Washer	1	
7	KADD0622	Bolt Flange M6	1	
8	JL561410	Washer Steel	1	
9	JL561409	Bolt socket - M8	1	
10	1100905	'O' Ring	2	
11	JL561222	Lever Change Assembly	1	
12	52JL2033	Tie Rod	1	
13	JL561414	Arm Change Lever with ball joint	1	
14	DH101509	Damper	1	
15	52JL2034	Lever Change Assembly complete	1	




Engine Assembly / Crankcase RH

No.	Part No.	Description	Qty.	Remarks
1	36JF0052	Kit Assembly Crankcase RH	1	
2	JL501145	Engine assembly	1	
3	39218520	Deep Groove Ball Bearing	1	
4	39256220	Needle Roller Bearing	1	
5	39260120	Ball Bearing	1	
6	39186420	Ball Bearing 20 X 52 X 15	1	
7	KPBF6304	Ball Bearing	1	
8	JY541047	Stopper I/P Shaft Bearing	3	
9	AA101437	Bolt Flanged	3	
10	JG601007	Special Shaft Seal	1	
11	JL601010	Water Seal Double Lip	1	
12	JG561204	Bolt Stopper Drum	1	
13	DP101191	Bolt Shifter	1	
14	JG571014	Oil Filter	1	
15	JG571016	'O' RING	1	
16	56JF1X36	Cap oil filter Silk matte blue	1	
17	KAEW0616	Flange Bolt	2	
18	LAE00001	Bolt Flanged	1	
19	JG561226	Spring Stopper Drum	1	
20	39200511	Washer	1	
21	JG561009	Stopper Drum Complete	1	
22	JG561205	Washer	1	




Crankcase LH

No.	Part No.	Description	Qty.	Remarks
1	52JF1711	Assembly Crankcase LH	1	
2	LJA00002	'O' Ring	2	
3	JY571008	Strainer Evacuation	1	
4	LJA00006	'O' Ring	1	
5	JY571009	Cap Strainer Evacuation	1	
6	39104319	Oil Seal	1	
7	JY541058	Oil Seal	1	
8	KEBA3715	Circlip Internal	1	
9	JY541031	Chain Guard	1	
10	LBB00007	Screw Pan Cross	3	
11	JY571030	Mesh Oil Filter Assembly	1	
12	LJA00004	'O' Ring	1	
13	JA541021	Cap strainer	1	
13A	59210023	O - Ring	1	
14	JP351005	Sensor assembly pick up	1	
15	JN181033	Bolt flange	2	
16	AA101437	Bolt M5 x 13	5	
17	JY541081	Bracket Harness	1	
18	JY541080	Plate Harness	1	
19	JY541082	Bracket Harness	1	
20	LPB00003	Bearing Ball	1	
21	LPB00002	Bearing Ball	1	
22	39256220	Needle Roller Bearing	1	
23	JF541017	Bracket	1	
24	LBB00012	Screw pan cross - M6	1	




Crankcase LH

No.	Part No.	Description	Qty.	Remarks
25	39218106	Hollow Dowel Pin	4	
26	KAEW0635	Bolt Flange Small	15	
27	LAE00002	Bolt Flanged	5	
28	JY571029	Oil Rail	1	
29	LJA00002	O Ring	1	
30	JF541016	Nozzle	1	
31	LAE00010	Bolt flange - M5	2	




Balancer Idler Gear & Water Pump

No.	Part No.	Description	Qty.	Remarks
1	JP531206	Assembly balancer	1	
2	KPBF6304	Ball Bearing	2	
3	36JL0039	Rotor Water Pump	1	
4	JG531215	Washer	1	
5	JG601005	Domed Nut	1	
6	JG601012	'O' Ring	1	
7	39260607	Parallel Pin	2	
8	JL601008	Cover Water Pump	1	
9	39166511	Washer	1	
10	LAE00048	Bolt	1	
11	KAEW0622	Bolt flange small M6	5	
12	DS101154	Key	1	
13	LDB00051	Washer	1	
14	LAC00086	Bolt Socket	1	
15	JF531213	Scissor Gear Assembly	1	




Oil Pump & Evacuation Pump

No.	Part No.	Description	Qty.	Remarks
1	JY571015	Evacuation Oil Pump Assy.	1	
2	LHD00001	Pin Parallel	3	
3	39099906	Pin Dowel	4	
4	LAE00018	Bolt Flanged M6 Pre Coated	6	
5	JY571024	Shaft Oil Pump	1	
6	JY571012	Oil Pump Assembly Complete	1	
7	JY571023	Gear Oil Pump Drive	1	
8	LDA00017	Washer Plain	1	
9	KEAB1010	Circlip External	1	




Cooling System

No.	Part No.	Description	Qty.	Remarks
1	JL601269	Radiator	1	
2	JL601260	Hose Radiator-thermostat	1	
3	JL601261	Pipe Coolant	1	
4	JG601235	Pressure Cap Radiator	1	
5	JF601400	Fan Radiator	1	
6	DT181265	Grommet Side Cover	2	
7	JG171029	Clamp	1	
8	JL601226	Tank Expansion	1	
9	JG601211	Cap Expansion Tank	1	
10	JL171101	Clamp Band Spring 9.5x8.4	1	
11	JF601220	Pipe Tank Expansion	1	
12	JG601230	Expansion Tank O Ring	1	
13	JG601213	Tube Drain - Expansion Tank	1	
14	DJ181065	Clip Nut M6	2	
15	JL601216	Rubber Damper Radiator Mounting	4	
16	LCG00029	Nut Hex Flanged M6x1	4	
17	JL601268	Cowl Radiator	1	
18	JP181233	Spacer Radiator Shroud	2	
19	JL601270	Collar	2	
20	JL181943	Bracket Shroud Rh	1	
21	JG601210	Clap Radiator Pipe Dia 28	3	
22	LAE00055	Bolt Flange-m6x1x16xcl8.8xblack	2	
23	JG601014	Unit Thermostat	1	
24	JY601215	Hose Coolant(eng To Therm)	1	
25	JF601210	Pipe Thermostat-joint T	1	




Cooling System

No.	Part No.	Description	Qty.	Remarks
26	JG601016	Clamp Radiator Pipe Dia 26	2	
27	JG601234	Clamp Dia 23	1	
28	JG601209	Clamp Radiator Pipe Dia 24	1	
29	JL113858	Bracket Radiator Rh	1	
30	JL113857	Bracket Radiator Lh	1	
31	KADD0610	Bolt Flanged M6x1	4	
32	JF601211	Joint Assembly T	1	
33	LJA00005	O Ring	1	
34	JL601215	Clamp Expansion Tank	1	




Cover Clutch

No.	Part No.	Description	Qty.	Remarks
1	52JF3163	Clutch cover assembly	1	
2	39199020	Needle Bearing	1	
3	39104119	Seal Oil	1	
4	LDB00020	Washer	1	
5	JF541210	Spring Lever Clutch	1	
6	JF541208	Clutch Release Shaft Assembly	1	
7	KJAA1424	'O' Ring	1	
8	JG541230	Cap Oil Filling	1	
9	JF233560	Decal cover clutch	1	
10	JL541227	Window Oil Gauge	1	
11	DS101215	Wire Circlip	1	
12	39201619	Seal Oil	1	
13	JY541220	Plate Position	1	
14	AA101437	Bolt Flanged Small	2	
15	JY541225	Gasket Clutch Cover	1	
16	JF541204	Bracket Clutch Cable	1	
17	KAEW0635	Blot Flanged	12	
18	JF161204	Clutch Cable	1	



Cover Magneto

No.	Part No.	Description	Qty.	Remarks
1	52JF3142	Magneto Cover Assembly	1	
2	JF233565	Decal cover magneto	1	
3	30101195	'O' Ring	1	
4	JL541245	Cap TDC Finder	1	
5	JY541214	Gasket Cover Magneto	1	
6	KAEW0635	Bolt Flange	12	
7	DT541202	Cover LH RR	1	
8	KAEW0650	Bolt Flange	3	
9	JF233036	Label Gear Shift 6 Speed	1	
10	39099906	Pin - Hollow Dowel	2	




Clutch Assembly & Clutch Cable

No.	Part No.	Description	Qty.	Remarks
1	JF551419	Clutch Assembly	1	
2	36JF0054	Kit Primary Drive & Driven	1	
3	JY551403	Washer Clutch	1	
4	JY551435	Clutch Center	1	
5	JY551442	Spring Seat Judder	1	
6	JY551441	Spring Judder	1	
7	36JF0195	Kit friction plate	1	
8	JY551436	Pressure Plate - A	5	
9	JY551437	Pressure Plate - B	1	
10	JY551401	Bush Collared	1	
11	LCG00009	Nut Hex Flanged - M16 x 1.5	1	
12	LPA00004	Thrust Bearing	1	
13	JY551438	Plate Clutch Pressure	1	
14	JY551404	Rod Pull	1	
15	JY551439	Seat spring	3	
16	JY551443	Plate Stopper	1	
17	LAD00166	Bolt Flanged - M6 x 35	3	
18	JY551019	Washer Plain	1	
19	DG101275	Washer Special	1	
20	JF161204	Clutch Cable	1	
21	JY551440	Seat Spring	3	




Throttle Body & Sensors

No.	Part No.	Description	Qty.	Remarks
1	JL611210	Body Throttle Assembly	1	
2	JL611211	Cap Injector-connector Quick	1	
3	JG611006	Injector Clip	1	
4	JP611003	Injector	1	
5	JG351805	Sensor Tmap	1	




Air Cleaner Assembly

No.	Part No.	Description	Qty.	Remarks
1	JL581134	Filter assembly air	1	
2	JH581202	Clamp Carb Sleeve Dia 44	1	
3	KAED0610	Bolt	1	
4	JL581146	Seal Top Cover	2	
5	KBUA0630	Screw Truss	4	
6	JL581138	Tube Breather	1	
7	JY581016	Clamp	1	
8	JG581056	Clamp (breather tube)	1	
9	JL581142	Air Filter Element	1	
10	JY581028	Clamp (Breather Tube)	1	
11	JP581018	Assembly Tube Drain	1	
12	JY581028	Clamp	2	
13	DT581074	Assly Breather Oil Return Tube	1	
14	JL113868	Bracket Filter Mounting	1	
15	JG181265	Washer	4	
16	KACF0612	Bolt Socket	4	




Silencer Assembly

No.	Part No.	Description	Qty.	Remarks
1	JL591454	Pipe Assembly A	1	
2	JL591447	Muffler Assembly	1	
3	JL591462	Shield Pipe A	1	
4	JL591149	Bolt Socket M5x0.8	3	
5	LCG00024	Nut Hex Flanged-m8x1.25xht.8xbrt	2	
6	JP591106	Gasket Exhaust	1	
7	JP591065	Sensor Oxygen	1	
8	JG591038	Band Clip	1	
9	KADD0635	Bolt Flanged M6x1	2	
10	JL591157	Sleeve Bottom	3	
11	JL591165	Damper Silencer Mounting Lower	4	
12	JG591039	Gasket Muffler Pipe-a	1	
13	JL591148	Bolt Hexagonal Flange	2	
14	JL591156	Sleeve Top	4	
15	DH101607	Truss Screw	6	
16	JL591486	Cap End	1	
17	JL591508	Shield Muffler	1	




Starter Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF351600	Starter Motor	1	
2	KADQ0625	Bolt Flanged	2	
3	JY551225	Gear Starter Counter 2	1	
4	JY551226	Gear Starter Counter 1 Assy.	1	
5	LAE00042	Bolt Flanged	1	
6	JY621411	Assembly Gear Starter Clutch	1	
7	JY541040	Retainer Gear Starter	1	




Magneto, Regulator & ECU

No.	Part No.	Description	Qty.	Remarks
1	JF351013	Rotor Without Clutch & BSC	1	
2	JL351068	Stator Assembly	1	
3	DK101284	Hex Socket Head Screw	3	
4	JF402004	Regulator Assembly	1	
5	KAED0630	Bolt - Flanged - Small	2	
6	JF181282	Bracket ECU lower	1	
7	TA351404	ECU	1	
8	JY113864	Bracket ECU mtg top C smple	1	
9	KCGA0606	Nut hex flanged	4	
10	JY551402	Clutch One Way Assly	1	
11	LDB00041	Plain Washer	1	
12	LAD00124	Bolt Flange	1	
13	JY541222	Plate Harness	1	
14	JY541208	Bracket Harness Magneto	1	
15	KADD0508	Bolt	3	
16	LDF00001	Washer toothed	4	
17	LAC00122	Bolt Socket	4	
18	JF351014	Body clutch starter	1	
19	JY113873	Pad resting ECU C sample RH	1	
20	JY113877	Damper ECU Locator	1	
21	JY113874	Damper ECU C smple mtg top	1	
22	JY171007	Pad rubber new ECU My16	2	
23	JY113872	Pad resting ECU C sample LH	1	




H.T. Coils

No.	Part No.	Description	Qty.	Remarks
1	JF351219	Coil HT Assembly	1	
2	KAED0625	Bolt flanged small	2	
3	DD111012	Grommet For H. T. Cable	1	
4	JY351203	Grommet spark plug cap	1	
5	JY351200	Cap spark plug	1	
6	JF351206	Grommet Spark Plug	1	
7	JL351218	Spark Plug BOSCH central	1	
8	DT113855	Clamp HT coils	1	




Seat Assembly & Seat Lock

No.	Part No.	Description	Qty.	Remarks
1	JL191001	Seat Assy Comp Front	1	
2	36JL0013	Kit Damper For Seat	1	
3	DK211007	Damper Seat Front	1	
4	JG191008	Collar -Seat	2	
5	FD211006	Grommet - Seat	2	
6	DS161287	Flange Bolt - M6	2	
7	JL191004	Seat Assy Comp Rear	1	
8	JD191006	Damper Round	2	
9	DT232605	Lock Assy Seat Rear	1	
10	JG232606	Seat Lock Cable	1	
11	KADD0622	Bolt Flanged	2	
12	JL232604	Cover Seat Lock Assembly	1	
13	DK211009	Damper	2	



Engine Mountings

No.	Part No.	Description	Qty.	Remarks
1	56DT0233	Stay hanger LH matt black	1	
2	56DT0333	Stay hanger RH matt black	1	
3	KAED0820	Bolt flanged small	4	
4	DT181323	Plug 2	2	
5	LAJ00020	Bolt stud - M10 X L153	1	
6	KDDB1018	Washer spring thin	1	
7	KDAA1018	Washer Plain	1	
8	LAA00051	Bolt - M8 (For LH & RH)	2	
9	LAD00006	Bolt Flange	2	
10	LCL00001	Hex Nut / Flange	2	
11	DT113827	Cover Seal Heat	1	




FWD Front Wheel Direction

Plate No.: 26

Frame and Frame Fittings

No.	Part No.	Description	Qty.	Remarks
1	56JL09CA	Frame Assembly Matt Gray+black	1	
2	JL111103	Cap Tube End	2	
3	DT111106	Frame Rubber Pad LH	1	
4	DT111107	Frame Rubber Pad RH	1	
5	36DK0159	Kit Steering Cone	1	
6	DK181051	Cage Bearing Steering Bottom	1	
7	DK181075	Nut Steering	1	
8	DK181076	Cup Steering	1	
9	JL113809	Grommet Air Filter Resting	1	
10	DT181323	Plug 2	1	
12	KAED0610	Bolt Flanged Small	1	
13	JF113859	Bkt. Valve Purge Rly Interlock	1	
14	DS161166	Frame Tape II	2	
15	JL113841	Clamp Tie Cable	10	
16	DS211004	Damper Seat I	2	For Fuel Tank Resting
17	DK181050	Cage Bearing Steering Top	1	
18	JL113865	Bracket Assembly	1	
19	JL171024	Damper Structure Mtg	2	
20	KADA0610	Bolt Flanged M6x1	2	
21	LAE00021	Bolt Flanged M6x1	2	




Front Wheel Direction

Plate No.: 27


Swing Arm & Rear Shock Absorber

No.	Part No.	Description	Qty.	Remarks
1	JL122044	Arm Assembly Swing	1	
2	JL122058	Shock absorber Rear	1	
3	JL113408	Bracket Engine Middle Rear	1	
4	LAC00019	Bolt Socket	2	
5	KADT0814	Bolt Flanged	2	
6	LAD00108	Axle	1	
7	DT113848	Cap Swing Arm Pivot	2	
8	DG171019	Seal-oil	2	
9	DK171006	Sleeve For Swing Arm	2	
10	DG171018	Bearing-needle	2	
11	JL122054	Slider Chain	1	
12	LBU00168	Screw Socket Step M6x1	2	
13	JL122060	Shield Slider Chain	1	
14	KAAD0610	Bolt M6x1	2	
15	JF113422	Spacer	1	
16	JF113423	Washer Plain	1	
17	DG171017	Nut	1	
18	JL181903	Cover Chain	1	
19	JL181944	Cap Cover Chain	1	
20	LBU00237	Screw Button Head Step M6x1	2	
21	JL181902	Pin	1	
22	DT131875	Clamp	1	
23	KAEF0622	Bolt Flanged M6x1	1	
24	AA111141	Clip H.t. Cable Holding	1	
25	KCBC0805	Nut Hex M8x1.25	2	




Swing Arm & Rear Shock Absorber

No.	Part No.	Description	Qty.	Remarks
26	KCGC0808	Nut Hex Flanged	2	
27	JF122104	Cap Tube Arm Swing	2	
28	JL122052	Adjuster Chain	2	




Belly Pan & Radiator Shroud

No.	Part No.	Description	Qty.	Remarks
1	JL181933	Bracket Belly Pan Rh	1	
2	JL181901	Bracket Belly Pan Lh	1	
3	KBUC0620	Screw Truss M6x1	4	
4	JY181255	Washer End Cap	8	
5	KADF0614	Bolt Flanged M6x1	2	
6	JL181723	Shroud Inner Lh	1	
7	JL181725	Shroud Rear Lh	1	
8	56JL24CA	Shroud Outer Lh	1	
9	KBRC4213	Screw Tapping Pan Cross Dia 4.2	8	
10	JL181724	Shroud Inner Rh	1	
11	JL181726	Shroud Rear Rh	1	
12	56JL25CA	Shroud Outer Rh	1	
13	JY181285	Screw Button Head-m6x1x10xblack	2	
14	LBU00155	Screw Button Head Step M6x1	4	
15	DJ181065	Clip Nut	4	
16	JL231404	Tape Insulation	1	



Rider & Pillion Foot Rest


No.	Part No.	Description	Qty.	Remarks
1	56JL5F4X	Holder Step RH	1	
2	56JRV64X	Step Assembly RH	1	
3	JL113012	Spring Torsion	2	
4	JL113033	Bracket Rear Brake Switch	1	
5	KADD0610	Bolt Flanged	1	
6	LAC00045	Bolt-Socket Dia-08 L-20	4	
7	56JL3X4X	Step Holder LH	1	
8	56JR3S4X	Step Assly Main LH	1	
9	36JL0041	Kit Main Step Hardware	2	
10	LDA00013	Washer Plain Dia 6.4XDia	1	
11	LAC00016	Bolt Socket	4	
12	56JL4J4X	Step Holder- Pillion LH	1	
13	LDB00018	Washer Plain	3	
14	56JL184X	Step Pillion LH	1	
14A	36JL0015	Kit Pillion Hardware	2	
15	56JL194X	Step Pillion RH	1	
16	56JL4K4X	Step Holder RH	1	
17	JR113091	Rubber Main Step	2	
18	KHAA2520	Pin Cotter	4	
19	JL113037	Pin Foot Step	4	
20	39105515	Nut	1	
21	JZ113061	Rubber Pad Footrest-Main	2	
22	JL113036	Rubber Pad Pillion Step	2	




Rider & Pillion Foot Rest

No.	Part No.	Description	Qty.	Remarks
23	DT113014	Lock Plate LH	1	
24	DT113015	Lock Plate RH	1	
25	JL113035	Bolt M6x1	2	

Front Fender




No.	Part No.	Description	Qty.	Remarks
1	JL181484	Protector Fork Lh	1	
2	JL181485	Protector Fork Rh	1	
3	JF181473	Collar	6	
4	LAC00063	Bolt Socket	6	
5	JL181209	Fender Rear Front	1	
6	KADD0614	Bolt Flanged M6x1	2	
7	JL181325	Plug	1	
8	JL181221	Foam-rear Fender Front	1	




Side Stand Assembly

No.	Part No.	Description	Qty.	Remarks
1	JL113229	Stand Side	1	
2	JL113231	Bracket Side Stand Mtg	1	
3	KADF0812	Bolt Flanged	1	
4	LAD00135	Bolt Flange - M8 x L70	1	
5	JF401405	Side Stand Switch	1	
6	LCH00001	Nut Nyloc - M10	1	
7	DF161102	Bolt For Side Stand Mounting	1	
8	JL401417	Magnet Holder	1	
9	JL113209	Spring Side Stand	1	
10	DH161146	Cover - Spring Side Stand	1	
11	JL113237	Cover Switch Stand Side	1	
12	KCBA0604	Nut Hex	1	




Tubeless Tyre & Wheel

No.	Part No.	Description	Qty.	Remarks
1	JL131039	Tyre Front	1	
2	DK151026	Valve Tubeless Tyre	2	
3	56JL604X	Front Wheel Satin Black	1	
4	56JL614X	Rear Wheel Satin Black	1	
5	JL131266	Tyre Rear	1	




Front Wheel Hub

No.	Part No.	Description	Qty.	Remarks
1	JL131057	Axle	1	
2	JG131020	Collar Assembly Wheel Front	1	
3	KPBC6202	Bearing - Ball	2	
4	DG151005	Seal Oil	1	
5	JG131001	Spacer Assembly Front Wheel	1	
6	DG151005	Seal - Oil	1	
7	JG131889	Disc 320 mm	1	
8	JL131058	Sensor Disc Front	1	
9	JD131811	Special Bolt M8	6	
10	JG131020	Collar	1	
11	LDB00029	Washer	1	
12	LCJ00002	Nut - U M14	1	
13	DK201164	Sensor speed wheel	1	
14	KADD0614	Bolt Flanged	1	
15	DT131878	Clamp W ABS Hose	1	
16	KEBB3515	Circlip Internal	1	
17	KACA0508	Bolt Socket	5	




Master Cylinder - Front

No.	Part No.	Description	Qty.	Remarks
1	JL132018	Cylinder master assy. front	1	
2	DJ191029	Bolt Front Bracket I	1	
3	DJ191030	Nut	1	
4	DH191062	Oil Window Kit	1	
5	DJ191031	Screw	2	
6	DE191029	Cover - Reservoir	1	
7	36PD0053	Kit Diaphragm	1	
8	36JL0319	Kit Fasting Cap	1	
9	DJ201109	Switch brake	1	
10	DJ191026	Washer - Copper	8	
11	GL131827	Bolt - Banjo	4	
12	36PD0051	Minor Kit M Cylinder	1	
13	36JL0320	Lever Kit	1	
14	36PD0050	Major Kit M Cylinder	1	




Caliper Assembly - Front

No.	Part No.	Description	Qty.	Remarks
1	JL132013	Caliper Assy Brake Front	1	
2	YJR05034	Screw Bleeder	1	
3	DJ151070	Bleeder Cap	1	
4	DH151039	Bolt Flange :- Re-coated (M8)	2	
5	JR131827	Disc Pad	1	
6	36JR0047	Minor Kit	1	
7	36JR0046	Major Kit	1	




Anti-Lock Brake System

No.	Part No.	Description	Qty.	Remarks
1	JL132024	ABS Unit Wet	1	
2	36JL0318	Hose Front M Cylinder to ABS Unit	1	
3	36JL0317	Hose ABS Unit to Front Caliper	1	
4	JF1138 52	Bracket ABS	1	
5	LAE000 42	Bolt flanged small	2	
6	DT131875	Clamp brake hose	1	
7	KAAA0622	Bolt	1	
8	DJ191026	Copper Washer	8	
9	GL131827	Benjo Bolt	4	
10	36JL0244	Hose Rear M Cylinder to ABS unit	1	
11	36JL0245	Hose ABS unit to Rear Caliper	1	
12	JL131992	Bracket Hose Brake Rear	1	
13	KCGC0606	Nut For Bracket Hose Brake Rear	1	
14	JL132023	Clamp Hose	1	
15	LAC00010	Bolt	2	




Rear Disc Brake Master Cylinder & Caliper

No.	Part No.	Description	Qty.	Remarks
1	JR131883	Caliper assembly rear	1	
2	JL132022	Assly Cylinder Master Brake Rr	1	
3	36JR0052	Kit Brake Fluid Reservoir	1	
4	DK151069	Banjo Bolt	2	
5	36DH4180	Kit Holder Bracket Caliper End	1	
6	36JL0323	Kit Hose - Reservoir	1	
7	LAD00077	Bolt	2	
8	DE191010	Copper Washer	4	
9	36DH4178	Kit Bleeder Screw End	1	
10	36DH4179	Kit Caliper Hardwares End	1	
11	36DH4175	Major Kit Rear Caliper	1	
12	36DH4177	Kit Minor Rear Caliper	1	
13	36DH4174	Disc Pad Set Rear Caliper	1	
14	30191038	Pin	1	
15	KDAA0611	Washer Plain	1	
16	KHAA2015	Pin Cotter	1	
17	36DH4176	Kit Piston Seal Rear Caliper	1	
18	36JR0049	Master Cyl. Major Kit	1	
19	36JL0322	Master Cyl. Minor Kit	1	
20	36DH4181	Kit Filler Union	1	
21	KADD0614	Bolt	1	
22	36JL0321	Master Cylinder Push Rod-fork Kit	1	



Rear Wheel Hub


No.	Part No.	Description	Qty.	Remarks
1	DK201164	Sensor speed wheel	1	
2	KADD0614	Bolt Flanged	1	
3	JL131203	Axle Rear	1	
4	LDB00029	Washer Rear Axle RH	2	
5	LCL00004	Nut U Flange - M8	6	
6	JL131211	Spacer for Coupling	1	
7	DT131214	Seal Oil	1	
8	KPAC6205	Bearing Ball Ordinary Clearance	1	
9	DT131213	Coupling - 6 Plug	1	
10	JG131228	Bolt - D	6	
11	DT131210	Sleeve	1	
12	JU131222	Damper Coupling	6	
13	KPBC6202	Bearing - Ball - C3 Clearance	1	
14	KEBB4217	Circlip Internal	1	
15	JL131216	Collar Bearing Assy	1	
16	KPBC6302	Bearing - Ball - C3 Clearance	1	
17	30151082	Seal Oil	2	
18	JF131861	Disc Rear Dia - 230 mm	1	
19	DH151040	Bolt Socket - M6 x 1 x L16	6	
20	TA131845	Sensor Disc Rear	1	
21	JG131220	Screw Pan Cross - M6 x 1 x L12	3	
22	DK151082	Spacer II	1	
23	DK151081	Spacer I	1	
24	LCJ00002	Nut - U - M14	1	
25	36JI0316	Kit Chain Sprocket	1	




Rear Brake Pedal

No.	Part No.	Description	Qty.	Remarks
1	JL161017	Brake Pedal	1	
2	KADD0610	Bolt Flanged	1	
3	JL131928	Assembly Brake Shaft	1	
4	DH191013	Spacer Brake Shaft assy.	1	
5	JL401406	Brake Switch - Rear	1	
6	59040025	Bolt Flanged	1	
7	JL113033	Bracket Rear brake switch	1	
8	JL161006	Spring Rear Brake Switch	1	
9	DH191006	Spring - Brake Pedal	1	
10	KJAA1424	'O' Ring	2	

Handle Bar Assembly




No.	Part No.	Description	Qty.	Remarks
1	JL401425	Switch Control Lh	1	
2	JL401426	Switch Control Rh	1	
3	JY161008	Lever Assembly Clutch	1	
4	JL161018	Assly Lever & Holder LH	1	
5	KDBF0512	Washer Plain	1	
6	JY161012	Sleeve Cam Lever Pivot	1	
7	LEA00001	Circlip External	1	
8	JY161011	Spring Return Main Lever	1	
9	JY161015	Washer Cam Spring	1	
10	JY161020	Cam Lever Clutch	1	
11	JY161019	Cam Lever Clutch	1	
12	JZ161028	Lever Pivot Bolt	1	
13	LBU00012	Screw Pan Cross	1	
14	JG401426	Switch Clutch	1	
15	KADT0625	Bolt Flanged	1	
16	JL151069	Grip Lh	1	
17	56JU5A1Q	Handle Holder Top	1	
18	DH181022	Weight Handlebar	2	
19	KACJ0655	Bolt Socket	2	
20	LAC00111	Bolt Socket	4	
21	56JLP24X	Handlebar	1	
22	56JU5B1Q	Handle Holder Bottom	1	
23	LAC00092	Bolt Soket	2	




Handle Bar Assembly

No.	Part No.	Description	Qty.	Remarks
24	39242511	Plain Washer	2	
25	TA151015	Damper	2	
26	TA151026	Spacer	2	
27	TA151015	Damper	2	
28	56JL3333	Bracket Upper	1	
29	KACF0830	Bolt Socket M8x1.25	2	
30	39242511	Plain Washer	2	
31	LCH00001	Nut Nyloc	2	
32	JY151011	Bolt Flanged	1	
33	36JL0279	Lock Set	1	
34	JL401403	Ignition Switch	1	
35	LAD00244	Bolt	2	



Front Fork


No.	Part No.	Description	Qty.	Remarks
1	JL121035	Fork front	1	
2	YJF19009	Lock Nut	2	
3	JF113851	Clamp hose	2	
4	YJL23001	LH Pipe Inner with Axle Clamp	1	
5	YJL23002	RH Pipe Inner with Axle Clamp	1	
6	JG121012	Fork top bolt	2	
7	YJL23006	Fork Outer Yube Sub Assembly	2	
8	LDB00036	Washer plain	2	
9	YJL23004	Piston rod assembly	2	
10	JU121009	Oil seal stopper (Circlip)	2	
11	YJL23005	Screw cap inner pipe	2	
12	JG121028	Outer dust cap	2	
13	LAC00010	Bolt socket - M6	2	
14	JG113832	Sleeve for abs hose clamp	2	
15	YJL23003	Main spring & Washer	2	
16	JF121020	Bracket assembly under	1	
17	JY121011	Bolt socket - M8	6	
18	JG121057	Oil seal kit for single leg assly.	2	
19	YJF19008	Rubber damper	2	




Petrol Tank, Cap Tank & Gauge Fuel

No.	Part No.	Description	Qty.	Remarks
1	JL171841	Fuel Tank Assly	1	
2	JL171073	Damper Tank Cvr Resting RR	1	
3	KACF0516	Bolt Socket	6	
4	JL171049	Damper Ring Tank Cap	1	
5	36JL0012	Kit Tank Damper	1	
6	JF171822	Fuel Pump	1	
7	JP171820	Plate Pressure Fuel Pump	1	
8	LAD00154	Bolt	6	
9	JL171063	Pipe Drain	1	
10	JY171146	Ring - O Fuel Pump	1	
11	JD171059	Damper	1	
12	JG171030	Clamp	1	
13	LAD00151	Bolt Flange - M8x1.25xL21.5	3	
14	DT171075	Collar	1	
15	JL171018	Grommet Tank Mtg Front	1	
16	JL171019	Collar	2	
17	JL171020	Grommet Tank Mtg Rear	2	

EVAP System



No.	Part No.	Description	Qty.	Remarks
1	JR171620	Canister	1	
2	JU171606	Valve Purge	1	
3	JL171867	Pipe Fuel	1	
4	JF171659	Pipe Fuel	1	
5	KADA0612	Bolt Flanged M6x1	2	
6	JG171086	Connector Tube Evap	1	
7	JF171807	Tube Canister Drain -k16b	1	
8	KCGA0606	Nut Hex Flanged M6x1	1	
9	JG171030	Clamp	2	
10	33141008	Clamp	4	
11	JZ171055	Strap Canister	2	
12	JL113830	Bracket Canister Mtg (k14)	1	
13	DG121025	Clamp	1	
14	DP121028	Clamp	1	
15	JL171618	Pipe Purge Valve to Connector	1	
16	DT171847	Pipe Fuel	1	




Fitting - Petrol Tank Cover

No.	Part No.	Description	Qty.	Remarks
1	JL171140	Cover Assembly Tank Middle	1	
2	JL171149	Bracket Cover Tank Lh	1	
3	JL171150	Bracket Cover Tank Rh	1	
4	JL171148	Cover Tank Inner Rh	1	
5	JL171147	Cover Tank Inner Lh	1	
6	JL171078	Pad Tank Cover	1	
7	KADD0514	Bolt Flanged	2	
8	39214124	Washer, Nylon	8	
9	LAC00022	Bolt Socket-special Head	2	
10	31161078	Washer Plain	2	
11	LAC00034	Bolt Socket	4	
12	LDB00023	Washer Plain	4	
13	JL171070	Tank Cover Grommet	4	
14	JL171071	Collar	4	
15	JL171024	Damper Structure Mtg	4	
16	JL171057	Damper -tank Sidecover	4	
17	KADA0516	Bolt Flanged	2	
18	KADD0616	Bolt Flanged	2	
19	JL171040	Collar	2	
20	KBUA0516	Screw Truss	8	
21	KBRC4213	Screw Tapping Pan Cross	16	
22	JG171031	Nut Clip M5	8	
23	JL171049	Damper Ring	1	



Fitting - Side Covers, Seat Cowl


No.	Part No.	Description	Qty.	Remarks
1	JL181955	Cover Mesh Rh	1	
2	JZ171124	Grommet	4	
3	JL181288	Screw Stepped	2	
4	KBUA0612	Screw Truss	2	
5	59020001	Self Tap Screw	10	
6	JL181954	Cover Mesh Lh	1	
7	JL181729	Cowl Seat Middle Inner	1	
8	JL181939	Cowl Seat Lh	1	
9	JL181940	Cowl Seat Rh	1	
10	JL181728	Cowl Seat Middle Upper	1	
11	JL181938	Cowl Seat Central	1	
12	JL181220	Grommet -2 Seat Cowl	2	
13	JL181219	Grommet -1 Seat Cowl	2	
14	KBUA0514	Screw Truss	7	
15	JK401801	Foam Battery Band	1	
16	JG171031	Nut Clip M5	7	
17	KBRC4813	Screw Tapping Pan	16	
18	LDA00007	Washer Plain	6	
19	LAL00003	Bolt	6	




Instrument Cluster & Socket Charger

No.	Part No.	Description	Qty.	Remarks
1	JL402424	Instrument Cluster	1	
2	JL181710	Structure Fairing	1	
3	JL403403	Socket Charger	1	
4	JL181922	Cover Speedometer Front	1	
5	JL181921	Flap Speedometer	1	
6	JG181238	Grommet Dashboard	2	
7	LDB00007	Washer Plain	2	
8	KCAA0504	Nut Hex	2	
9	GL181263	Bead Front Shield	6	
10	JU181912	Collar	2	
11	JL181730	Grommet	2	
12	LAD00311	Bolt Flanged Step	1	
13	JR181781	Grommet	2	
14	JG113404	Clip Nut	1	
15	LAC00054	Bolt Socket	2	
16	JP181232	Sleeve Radiator	2	
17	JL181931	Bracket Pivot Lower	1	
18	LBU00145	Screw Button Head	2	
19	JH181426	Grommet Under Tray	2	

LED Head Lamp & Fairing




No.	Part No.	Description	Qty.	Remarks
1	JL401030	Lamp DRL Lh	1	
2	JL401031	Lamp DRL Rh	1	
3	JL401032	Lamp Head	1	
4	LBU00065	Screw Truss	2	
5	LDB00074	Washer Plain	2	
6	JL181919	Carrier Mask	1	
7	BF182539	Washer	10	
8	KBUC0510	Screw Truss	4	
9	KBRA4216	Screw Tapping	4	
10	05161256	Clip Nut-m6	2	
11	39183911	Washer Plain	4	
12	JF181362	Foam	2	
13	JG171031	Nut Clip M5	2	
14	JL181925	Fairing Rear Lh	1	
15	KBRA4213	Screw Tapping Pan Cross	6	
16	DT401017	Pivot Screw	2	
17	JL181920	Windshield	1	
18	JL181247	Grommet Wind Screen Mounting	1	
19	JF181277	Well-nut For Mask	2	
20	JG181235	Washer Special	2	
21	LBS00002	Screw Csk-socket	2	
22	JL181926	Fairing Rear Rh	1	
23	GL181817	Tape Dual Lock	4	
24	JL181950	Tape	2	




LED Head Lamp & Fairing

No.	Part No.	Description	Qty.	Remarks
25	JL181947	Protector Assly	1	
26	JL181948	Tape	1	
27	JL181949	Tape	2	




Indicator Light Assembly

No.	Part No.	Description	Qty.	Remarks
1	JP401019	Indicator Assembly Fr Rh	1	
2	JP401018	Indicator Assembly Fr Lh	1	
3	KCBA1006	Nut Hex M10x1.25	2	
4	KDFB1018	Washer Toothed Internal	2	
5	KDAA1018	Washer Plain	2	
6	JY401024	Indicator Assembly Rr Lh	1	
7	JY401025	Indicator Assembly Rr Rh	1	
8	LCL00001	Nut Flanged	2	




Tail Lamp Assembly & Number Plate Mounting

No.	Part No.	Description	Qty.	Remarks
1	JL401002	Lamp Tail Assy	1	
2	JG171031	Nut Clip M5	3	
3	KBUA0514	Screw Truss	3	
4	56JLBP4X	Bracket Indicator Rear	1	
5	LAD00149	Bolt Flanged	2	
6	PA402204	Band(length 110mm)	4	
7	JY401042	Reflector Reflex	2	
8	KCAC0605	Nut Hex M6x1	1	
9	PF181416	Collar	2	
10	KCGA0606	Nut Hex Flanged M6x1	4	
11	JL232893	Extension Structure Plate No Rr	1	
12	JG401006	Number Plate Illumination Lamp	1	
13	KBRD4213	Screw Tapping	2	
14	JU401024	Reflector Reflex	1	
15	KCGC0505	Nut Hex Flanged	1	
16	JF232807	Bracket Plate Number Rear	1	
17	LBU00128	Screw Button Head M6x1	2	
18	JZ232805	Foam Rear Number Plate	1	
19	05161256	Clip Nut-m6	2	
20	JL232883	Bracket Plate Number Front	1	
21	39150811	Washer Plain	2	



Electrical Equipments


No.	Part No.	Description	Qty.	Remarks
1	JL402311	Harness wiring	1	With grommets
2	JL403000	Relay Inter lock	5	
3	JG402229	Fuse 15A	6	
4	JG402230	Fuse Mini 30A	1	
5	DT402226	Fuse 7.5A Mini	2	
6	JG402228	Fuse 10A	1	
7	JP403002	Damper Relay Starter	1	
8	JL380605	Earth Cable	1	
9	JU401602	Horn	1	
10	KDBB0818	Washer Plain	1	
11	KADF0814	Bolt Flanged	1	
12	PA402207	Cable Relay - Motor	1	
13	DH201124	Relay Starter	1	
14	JF181272	Battery Case	1	
15	KAEA0622	Bolt flanged	3	
16	KADD0616	Bolt Flanged	1	
17	PA402204	Band (Length 110 mm)	2	
18	JD402212	Band (Length 200 mm)	17	
19	JD402217	Band (Length 150 mm)	7	
20	KACF0612	Bolt Socket - M6 x 1 x L12	2	
21	JF113842	Bracket Sensor Roll Over	1	
22	LAC00008	Screw Button Head - M6	2	
23	JY403604	Sensor Roll Over	1	
24	KCHA0608	Nut Nyloc	2	
25	JF171064	Band Cable	1	
26	JY113864	Bracket ECU Mtg Top C Sample	1	
27	JY171007	Pad Rubber New ECU	2	




Electrical Equipments

No.	Part No.	Description	Qty.	Remarks
28	JY113874	Damper ECU C Sample Mtg Top	1	
29	JY113877	Damper ECU Locator	1	
30	JF181282	Bracket ECU Lower	1	
31	JY113872	Pad Resting ECU C Sample LH	1	
32	JY113873	Pad Resting ECU C Sample RH	1	
33	KCGA0606	Nut Hex Flanged	4	
34	TA351404	ECU EMS	1	
35	JF181308	Rubber Battery Case	1	
36	JL113825	Band Battery Case - Vert ECU	1	
37	DT181022	Band Battery Case	1	
38	36JU0015	Kit Battery 12V 8Ah	1	
39	JF402004	Regulator	1	
40	KAED0630	Bolt Flanged	2	

Tool Kit



No.	Part No.	Description	Qty.	Remarks
1	JF231068	Tool kit	1	Not Serviceable
2	DK221024	Tool kit band	2	



 Front Wheel Direction

Plate No.: 52

Accessories - Mirror, Grab Handles & Saree Guard

No.	Part No.	Description	Qty.	Remarks
1	56JL5U33	Grab Handle LH	1	
2	56JL5V33	Grab Handle RH	1	
3	LAC00035	Bolt Master	4	
4	JL231222	Guard Saree	1	
5	JL231236	Cover Structure Inner	1	
6	JL231237	Cover Structure Outer	1	
7	LBU00247	Screw Button Head M10x1.25	2	
8	KDBB1022	Washer Plain	2	
9	JF231608	Mirror LH	1	
10	JF231609	Mirror RH	1	
11	JF231239	Guard Leg LH	1	
12	JF231240	Guard leg RH	1	
13	KDAB0816	Washer Plain Small	2	
14	LAC00165	Bolt socket - M8 x 1.25	2	
15	LBR00002	Screw Tapping Pan Dia 5	2	
16	LCL00007	Nut U flanged - M8	2	
17	JL181489	Fender Hugger	1	
18	LDH00016	Washer conical	2	
19	KDAA0816	Washer plain small	2	
20	LAC00141	Bolt socket - M8	2	
21	LAC00037	Screw Butn	2	
22	JL231402	Foam Grab Handle LH	1	
23	JL231403	Foam Grab Handle RH	1	

Painted Parts and Decals



No.	Part No.	Description	Qty.	Remarks
1	52JL2968	Cowl Seat Outer Lh Pewter Grey	1	
	52JL2946	Cowl Seat Outer Lh Brooklyn Black	1	
	52JL2935	Cowl Seat Outer Lh+Decal	1	
	52JL2956	Cowl Seat Outer Lh Pearl Met White	1	
2	52JL2969	Cowl Seat Outer Rh Pewter Grey	1	
	52JL2947	Cowl Seat Outer Rh Brooklyn Black	1	
	52JL2936	Cowl Seat Outer Rh+Decal	1	
	52JL2957	Cowl Seat Outer Rh Pearl Met White	1	
3	52JL2959	Side Mask Lh Assly Pewter Grey	1	
	52JL2931	Side Mask Lh Assly Racing Red	1	
	52JL2941	Side Mask Lh Assly Brooklyn Black	1	
	52JL2949	Side Mask Lh Assly Pearl Met White	1	
4	52JL2960	Side Mask Rh Assly Pewter Grey	1	
	52JL2930	Side Mask Rh Assly Racing Red	1	
	52JL2942	Side Mask Rh Assly Brooklyn Black	1	
	52JL2950	Side Mask Rh Assly Pearl Met White	1	
5	52JL2928	Asly Side Cover Lh Satin Black	1	
6	52JL2927	Assy Side Cover Rh Satin Black	1	
7	52JL2869	Belly Pan Assly Lh Ebony Black	1	
	52JL2962	Belly Pan Assly Lh Pewter Grey	1	
8	52JL2868	Belly Pan Assly Rh Ebony Black	1	
	52JL2961	Belly Pan Assly Rh Pewter Grey	1	
9	56JLCU4X	Cvr Tank Lh JI171147 Satin Black	1	
10	56JLCV4X	Cvr Tank Rh JI171148 Satin Black	1	


Painted Parts and Decals



No.	Part No.	Description	Qty.	Remarks
11	56JLT195	Fairing S Inner Lh Rac Red	1	
	56JLT19V	Fairing Side Inner Lh Brooklyn Black	1	
	56JLT142	Fairing Side Inner Lh Perl Met Whit	1	
	56JLT132	Fairing Side Inner Lh Pewter Grey	1	
12	56JLT295	Fairing S Inner Rh Rac Red	1	
	56JLT29V	Fairing Side Inner Rh Brooklyn Black	1	
	56JLT242	Fairing Side Inner Rh Perl Met Whit	1	
	56JLT232	Fairing Side Inner Rh Pewter Grey	1	
13	52JL2937	Frnt Fnder Assly + White Red Decal	1	
	52JL2970	Frnt Fnder Assly+Pewter Grey Decal	1	
14	52JL2954	Tank cover Top Pearl Met White+Decal	1	
	52JL2966	Tank Cover Top Pewter Grey+Decal	1	
	52JL2938	Tank Cover Top Racing Red+Decal	1	
	52JL2945	Tank Cover Top Brooklyn Black+Decal	1	
15	52JL2952	Tank Flap Lh Pearl Met White+Dcl	1	
	52JL2964	Tank Flap Lh Pewter Grey+Dcl	1	
	52JL2939	Tank Flap Lh Racing Red+Dcl	1	
	52JL2943	Tank Flap Lh Brooklyn Black+Dcl	1	
16	52JL2953	Tank Flap Rh Pearl Met White +Dcl	1	
	52JL2965	Tank Flap Rh Pewter Grey +Dcl	1	
	52JL2940	Tank Flap Rh Racing Red+Dcl	1	
	52JL2944	Tank Flap Rh Brooklyn Black+Dcl	1	
17	36JL0314	Kit Decal Belly Pan Lh	1	
	36JL0313	Kit Decal Belly Pan P Grey Lh	1	




Painted Parts and Decals



No.	Part No.	Description	Qty.	Remarks
18	36JL0300	Kit Decal Cover Tank E Blk	1	
	36JL0302	Kit Decal Cover Tank P Grey	1	
	36JL0301	Kit Decal Cover Tank P M Wh	1	
	36JL0299	Kit Decal Cover Tank Red	1	
19	36JL0308	Kit Decal Cowl Seat E Black	1	
	36JL0310	Kit Decal Cowl Seat P Grey	1	
	36JL0309	Kit Decal Cowl Seat P M White	1	
	36JL0307	Kit Decal Cowl Seat R Red	1	
20	36JL0311	Kit Decal Fender Front	1	
	36JL0312	Kit Decal Fender Front P Grey	1	
21	36JL0304	Kit Decal Flap Tank E Black	1	
	36JL0306	Kit Decal Flap Tank P Grey	1	
	36JL0305	Kit Decal Flap Tank P M White	1	
	36JL0303	Kit Decal Flap Tank R Red	1	
22	JF233560	Decal Cover Clutch	1	
23	JF233565	Decal Cover Magneto	1	
24	JL233506	Decal Fairing Ebony Black Lh	1	
	JL233520	Decal Fairing Pearl M White Lh	1	
	JL233528	Decal Fairing Pewter Grey Lh	1	
	JL233492	Decal Fairing Racing Red Lh	1	
25	JL233507	Decal Fairing Ebony Black Rh	1	
	JL233521	Decal Fairing Pearl M White Rh	1	
	JL233529	Decal Fairing Pewter Grey Rh	1	
	JL233493	Decal Fairing Racing Red Rh	1	

Painted Parts and Decals



No.	Part No.	Description	Qty.	Remarks
26	JL233556	Decal Faring Front	1	
27	JF233611	Decal Pulsar	2	
28	JL233554	Decal Wheel Lh	2	
	JL233546	Decal Wheel Pewter Grey Lh	2	
29	JL233547	Decal Wheel Pewter Grey Rh	2	
	JL233555	Decal Wheel Rh	2	
30	JF233288	Emblem Fuel Injection Lh	1	
31	JF233289	Emblem Fuel Injection Rh	1	

1		2		3	
4		5		6	
7		8		9	
10		11		12	



Front Wheel Direction

Plate No.: 54

Consumable Parts

No.	Part No.	Description	Supply Unit	Application
1	83020576 83020578 83020577	Oil Bajaj DTS-i 10W50 BS VI Oil Bajaj DTS-i 10W50 BS VI Oil Bajaj DTS-i 10W50 BS VI	1.2 Ltr. 1 Ltr. 100 ML.	Top Up
2	36001058	Bajaj Coolant Koolex*	1 Ltr.	Coolant Top-up/Replace
3	36DH4061	Brake Fluid DOT4	100 ml	Disc Brake Top-up/Replace
4	36DH4052	Silicon grease	3 gm	Caliper Pin
5	83020473 36DK0045	Grease Petamo GHY 441 Grease Molycoat	3 gm 200 gm	Water Pump Seals For Starter Clutch Lubrication
6	36JL0181	Limaplex HTX 3 Grease	10 gm	Steering Race
7	83020173	Multi Purpose Grease* (Local Purchase)	--	Lubrication of Clutch Lever, Brake Lever, Brake Pedal & Side Stand
8	36001055	Chain Lubricant HP Make	1 kg	Non - Sealed Chain Lubrication
9	36001062	Liquid gasket L5910	50 ml	Crankcase Joining
10	36314004 36JG0087	Fork oil Fork oil 480 ml (Dominar UG)	160 ml 480 ml	Front Fork Top-up/Replace\ Front Fork Top-up/Replace\
11	36DH4029	Kit Spray Chain Lub	100 ml	Sealed Drive Chain
12	36DH4071	Wonderfill Chain Spray	100 ml	Sealed Drive Chain

* Marked items to be arrange from vendor or local market. Not applicable against chassis number.

13		14		15	
16		17		18	
19		20		21	
22		23		24	



Front Wheel Direction

Plate No.: 54

Consumable Parts

No.	Part No.	Description	Supply Unit	Application
13	36DH4072	Rust Remover Spray Make - Zorric 88 & Wonder fill easiner	100 ml	For Removing Rust from Components
14	76010936	Loctite Thread locker 243*	50 ml	For Screws & Bolts
15	76010937	Loctite retaining compound 638*	50 ml	For Screws & Bolts
16	37004352	Touch up paint slate grey*	440 ml	Touch up of Frame, Swing Arm & Step Holder
17	37004353	Touch up paint Matte Silk black*	440 ml	Touch up of Grab Handle, Handle Bar & Handle Holder
18	36001060	Kibatsu touch up paint*	400 cc	Touch up of Cylinder head, Block & Alloy Wheels
19	37224018	Paint Bottle Schwartz Black*	--	P-200NS Frame Touch-up
20	75680236 NA	Petroleum Jelly (Local Purchase) Distilled Water (Local Purchase)	-- 1 Ltr.	For Battery Terminals For Battery Level Top-up
21	NA	SAE 90 oil (Local Purchase)	--	
22	62305084	WD40 Spray (Local Purchase)	400 ml	Electrical Contact Cleaning Spray
23	36001056	Carburetor Cleaning Spray*		For Cleaning Carburetor/ Throttle Body
24	37254039	Corrosion Protection Spray* Proto quick LTP902	--	For Preventing vehicle parts from rusting

* Marked items to be arrange from vendor or local market. Not applicable against chassis number.

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	36JF0052	Assembly crankcase RH	JF541013	Crankcase RH sub assembly (Plug + breather pipe)	1
			JY541023	Bush crankshaft	1
			39256220	Needle roller bearing	1
			JY541038	Bush	1
			JY541018	Bush insert	1
			JG601007	Special shaft seal ring (oil)	2
			LEB00001	Circlip internal	1
2	36JF0198	Kit valve repair K10UG	JF511257	Seat spring valve	4
			PD511246	Spring valve	4
			PD511208	Retainer spring valve	4
			CB101022	Cotter valve	8
			CB101009	Seal valve stem	4
3	36JF0053	Assly clutch cover With Nozel	DT541204	Clutch cover with plug	1
			39199020	Bearing - needle	1
			JG541021	Oil nozzle	2
4	36JF0054	Primary drive & driven	JY551212	Gear primary drive	1
			JF551412	Clutch outer complete	1
5	36JF0195	Kit friction plate K10UG	JF551421	Disc friction - A	4
			JY551420	Disc friction - C	3
6	36JF0197	Kit cam chain guide K10UG	JY511227	Guide chain slack side	1
			JY511229	Guide chain tight side	1
7	36JF0196	Kit block piston K10UG	JF521009	Block cylinder	1
			JF521216	Piston assembly	1
8	36JF0060	Piston ring set	JF521215	Ring piston top	1
			JF521212	Ring piston second	1
			JF521213	Ring piston oil	1
9	36DK0159	Steering cone	DK181050	Cage Bearing Steering Top	1
			36DV0007	Kit Steering Cone (New)	1
			DG181003	Washer	1
			DG181004	Seal - Oil	1
			DK181051	Cage Bearing Steering Bottom	1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
10	36DT0004	Tie band-W harness	JD402212	Band 200 mm	8
			JD402217	Band 150 mm	2
			PA402204	Band 110 mm	2
11	36JL0316	Kit Chain Sprocket	JY551029	Sprocket Drive	1
			JG141001	Chain 520 H O Rings	1
			JG141002	Sprocket Driven	1
12	36JL0317	Kit Hose Unit Abs-Caliper Front	JL132019	Hose Unit Abs-Caliper Front	1
			GL131827	Bolt Banjo	2
			DJ191026	Copper Washer	4
13	36JL0318	Kit Hose Cyl Master Fr-Unit Abs	JL132020	Hose Cylinder Master Fr-Unit Abs	1
			GL131827	Bolt Banjo	2
			DJ191026	Copper Washer	4
14	36JL0319	Fastening Cap Kit	YJL23007	Fastening Cap Finished	1
			YJL23008	Fastening Cap Screw	2
15	36JL0320	Lever Kit	YJL23009	Brake Lever Primary	1
			YJL23011	Brake Lever Secondary	1
			YJL23012	Knob For Adjustable Cam	1
			YJL23013	Rivet	1
			YJL23014	Lever Spring	1
			YJL23015	Plain Washer 3	1
			YJL23016	Plain Washer 2	1
			YJL23017	Plain Washer 1	2
			YJL23018	Bush	1
16	36JL0321	Master Cylinder Push Rod-Fork	KitYJL23019	Push Rod For Rear M/Cyl.-K4/K11 2Ch	1
			YJL23021	Push Rod Fork	1
			YJL23022	Hexagonal Lock Nut,M6X1	1
17	36JL0322	Master Cyl Seal Kit	YJL23023	Primary Lip Seal Dia 12	1
			YJL23024	Secondary Grommet Dia 12	1
			YJL23025	Diaphragm Seal	1
			YJL23026	Protection Boot	1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
18	36JL0323	Hose Tube -Clamp Kit	YJL23027 YJL23028	Reservoir Hose Tube Hose Clamp	1 2
19	36JL0299	Kit Decal Cover Tank Red	JL233495 JL233494 JL233497 JL233496	Decal Cover Tank Upper R Red Rh Decal Cover Tank Upper R Red Lh Decal Cover Tank Lower R Red Rh Decal Cover Tank Lower R Red Lh	1 1 1 1
20	36JL0300	Kit Decal Cover Tank E Blk	JL233508 JL233510 JL233509 JL233511	Decal Cover Tank Upper E Blk Lh Decal Cover Tank Lower E Blk Lh Decal Cover Tank Upper E Blk Rh Decal Cover Tank Lower E Blk Rh	1 1 1 1
21	36JL0301	Kit Decal Cover Tank P M Wh	JL233522 JL233523 JL233524 JL233525	Decal Cover Tank Upper P M Wh Lh Decal Cover Tank Upper P M Wh Rh Decal Cover Tank Lower P M Wh Lh Decal Cover Tank Lower P M Wh Rh	1 1 1 1
22	36JL0302	Kit Decal Cover Tank P Grey	JL233535 JL233534 JL233532 JL233533	Decal Cover Tank Upper P Grey Rh Decal Cover Tank Upper P Grey Lh Decal Cover Tank Lower P Grey Lh Decal Cover Tank Lower P Grey Rh	1 1 1 1
23	36JL0303	Kit Decal Flap Tank R Red	JL233498 JL233499 JL233500 JL233501	Decal Flap Tank Lower R Red Lh Decal Flap Tank Lower R Red Rh Decal Flap Tank Upper R Red Lh Decal Flap Tank Upper R Red Rh	1 1 1 1
24	36JL0304	Kit Decal Flap Tank E Black	JL233512 JL233513 JL233514 JL233515	Decal Flap Tank Lower E Black Lh Decal Flap Tank Lower E Black Rh Decal Flap Tank Upper E Black Lh Decal Flap Tank Upper E Black Rh	1 1 1 1
25	36JL0305	Kit Decal Flap Tank P M White	JL233526 JL233527 JL233600 JL233601	Decal Flap Tank Lwr P M White Lh Decal Flap Tank Lwr P M White Rh Decal Flap Tank Upr P M White Lh Decal Flap Tank Upr P M White Rh	1 1 1 1
26	36JL0306	Kit Decal Flap Tank P Grey	JL233536 JL233537	Decal Flap Tank Lower P Grey Lh Decal Flap Tank Lower P Grey Rh	1 1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
			JL233604 JL233605	Decal Flap Tank Upper P Grey Lh Decal Flap Tank Upper P Grey Rh	1 1
27	36JL0307	Kit Decal Cowl Seat R Red	JL233502 JL233503 JL233504 JL233505	Decal Cowl Seat Upper R Red Lh Decal Cowl Seat Upper R Red Rh Decal Cowl Seat Lower R Red Lh Decal Cowl Seat Lower R Red Rh	1 1 1 1
28	36JL0308	Kit Decal Cowl Seat E Black	JL233516 JL233517 JL233518 JL233519	Decal Cowl Seat Upper E Black Lh Decal Cowl Seat Upper E Black Rh Decal Cowl Seat Lower E Black Lh Decal Cowl Seat Lower E Black Rh	1 1 1 1
29	36JL0309	Kit Decal Cowl Seat P M White	JL233530 JL233531 JL233602 JL233603	Decal Cowl Seat Upr P M White Lh Decal Cowl Seat Upr P M White Rh Decal Cowl Seat Lwr P M White Lh Decal Cowl Seat Lwr P M White Rh	1 1 1 1
30	36JL0310	Kit Decal Cowl Seat P Grey	JL233538 JL233539 JL233606 JL233607	Decal Cowl Seat Upper P Grey Lh Decal Cowl Seat Upper P Grey Rh Decal Cowl Seat Lower P Grey Lh Decal Cowl Seat Lower P Grey Rh	1 1 1 1
31	36JL0311	Kit Decal Fender Front	JL233548 JL233549	Decal Fender Front Lh Decal Fender Front Rh	1 1
32	36JL0312	Kit Decal Fender Front P Grey	JL233557 JL233558	Decal Fender Front P Grey Lh Decal Fender Front P Grey Rh	1 1
33	36JL0313	Kit Decal Belly Pan P Grey Lh	JL233541 JL233545 JL233543 JL233544	Decal Belly Pan Lower P Grey Lh Decal Belly Pan Lower P Grey Rh Decal Belly Pan Upper P Grey Lh Decal Belly Pan Upper P Grey Rh	1 1 1 1
34	36JL0314	Kit Decal Belly Pan Lh	JL233550 JL233551 JL233552 JL233553	Decal Belly Pan Lower Lh Decal Belly Pan Lower Rh Decal Belly Pan Upper Lh Decal Belly Pan Upper Rh	1 1 1 1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit

Amendment Sheet

[illegible]

Amendment Sheet

[illegible]

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

pulsar
NS400

Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

pulsar
NS400

Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

pulsar
NS400

Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

pulsar
NS400

Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

pulsar
NS400

Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

pulsar
NS400

Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

Part Index



Part Number	Figure No.	Page No.

Part Number	Figure No.	Page No.

